

Install the Optional Bin Insert

Use this procedure to install the Optional Bin Insert into the external bin for the Catalyst 6000\6000N. This insert will help prevent discs from getting stuck in the output bin.

Required Tools

- Optional Bin Insert



Install the Optional Bin Insert

1. Identify the opening in the output bin that matches the key on the bottom of the bin insert.



Key on the bottom of the insert



Opening in the the bin

R I M A G E[®]

2. With the white label facing the side of the output bin, place the insert into the bin, with the key on the insert inserting into the opening in the bin.



Your system is now ready for operation.