RIMAGE®

Changing the Media Type Settings

This document contains the instructions of changing the media type settings for RSS 9.2 and later.

Required Tools

- No tools required

RSS 9.2 and later

1. Open **Rimage System Manager**
2. Select the **Configure Bins…** option to bring up the Bin Configuration Settings screen.

3. From the **Media type** dropdown list, select the appropriate **media type settings**
   Notes:
   - o In Rimage system that only has one input bin, the **Media type** dropdown list is not available.

4. From each of the **Bin** configuration dropdown lists, select the appropriate media type that each bin will hold.
   Notes:
   - o If you have Combination selected for your **Media Type**, you must have two different media types selected for your bin configurations.
   - o You must have at least one Output bin and one Reject bin. Output/Reject does count for this.
5. Select **OK**. The *Bin Configuration* Settings screen closes, and Rimage System Manager should now update the Media portion your configuration settings.